

The **Konftel 300Wx** is a battery-driven wireless conference phone that connects to a wireless base unit.



Wireless base unit connects to Ethernet and power using supplied cables. Status light will be solid green if successfully connected (may take up to 2 minutes).

SD memory card port

It is possible to record a call in progress and use the Konftel 300Wx as a dictaphone.

Press the **• ←** button to start and stop recording. Recordings can be accessed via the menu.

LEDs

Flashing blue	Incoming call
Steady blue light	Call in progress
Flashing red	Hold, microphone and speaker turned off
Steady red light	Mute, microphone turned off

Display symbols

21 AUG 10:25

KONFTEL 300Wx

Signal strength

Date

Time

Battery status


Fully charged

< 1 hr talk time


Charging the battery

Charge the battery by placing the Konftel 300Wx on the charging stand or plug the power cable into the Konftel 300Wx.

A fully-charged battery provides up to 60 hours of talk time. The Konftel 300Wx lets you know when there is less than one hour of talk time left.



DESCRIPTION



ANSWERING AND MAKING CALLS

- ⇒ Press  to answer an incoming call.
- ⇒ Dial the number and press  to make a call.
- ⇒ Press an arrow key to open a call list containing previously dialled numbers. Call using .
- ⇒ Press and hold an alphanumeric button for two seconds to call a contact in the phonebook.

DURING A CALL

- ⇒ Adjust the speaker volume using the keys  and .
- ⇒ Press  to turn off the microphone.
- ⇒ Press  to put the call on hold.
Both the microphone and the speaker are turned off and the call is on hold.
- ⇒ Press the same button again to reconnect the call.

ADDING A PARTY TO A CALL

- ⇒ Press the  button during the call.
Calls in progress are put on hold and a second dialling tone is heard.
- ⇒ Dial the second participant's number, press and wait for an answer.
- ⇒ Press the  button to connect all the meeting participants.

